


# Manual Dishwashing



## SCRAPE

**Scrape,  
Prewash  
& Soak**

## WASH

**Wash with  
detergent in  
clean warm  
water**

## RINSE

**Rinse in clean  
warm water**


## SANITIZE

**Sanitize in  
clean water  
with:**

- ♦ 50-200ppm chlorine
- OR-
- ♦ 200-400ppm quaternary

## AIR DRY

**Do NOT  
rinse or  
towel dry**



Use a chemical test strip to ensure proper sanitizer strength. Be sure to use the correct test strip for the type of sanitizer.

**Sanitizer  
contact  
time is  
important!!**